



FITS ALL CURRENT IPADS

MULTIPLE ADAPTERS INCLUDED

1

Home Button Access:

For iPad Pro (10.5"), iPad Air (10.5"),
iPad 9(10.2"), iPad 8(10.2"), iPad 7(10.2")



2

Hard Button Cover:

For iPad Pro (10.5"), iPad Air (10.5"),
iPad 9(10.2"), iPad 8(10.2"), iPad 7(10.2")



3

Camera Cutout (on side)

For iPad Pro (11"), iPad Air (10.9"),
iPad10(10.9")



4

No Home Button Access:

For iPad Pro (10.5"), iPad Air (10.5"),
iPad 9(10.2"), iPad 8(10.2"), iPad 7(10.2")



